

# Dædalus

DUAL  
REVERB W/  
EXPRESSION

## REVERB

Controls the overall amount of reverb. Similar to a wet/dry mix knob, only the initial note is always heard in the mix.

## DEPTH

Controls the length of the reverb decay.

## PREAMP

Increases the size of the reverb even further. Also, boosts the level of any effect that's placed in the EXP jack input.

BYPASS  
ON/OFF



BYPASS  
LED

REVERB II  
LED

## BLEND

Controls how much of the external pedal or device is heard in the reverb trails. This control corresponds to the device that's inserted into the EXP jack input (FX loop).


## REVERB II

Controls the amount of reverb when the right footswitch is engaged. This allows the player access to two separate levels of reverb on the fly!

REVERB II  
ON/OFF

## EXPRESSION JACK (EXP)

Plug in a TRS splitter cable to place any effect in to the decay of the reverb. Using the Blend knob, control how much of this effect is cycled into the signal. With an expression pedal in the loop, the treadle now controls the reverb amount. The reverb knob setting now becomes the treadle in toe down position. **Tip = Send, Ring = Return**



IN/OUT: 1/4" Inst. Cable | EXP: TRS Y-Cable

POWER CONSUMPTION: 9V @ 35mA | 18V @ 55mA

Standard 2.1mm x 5.5mm center negative power supply. Daedalus has internal polarity protection. We recommend using an isolated power supply over daisy chain options.