

POLARIS

ANALOG
CHORUS
& VIBRATO

VOLUME
Controls the overall output volume. Ranges from a strong boost to a full signal cut.

tone
Fine tunes the low and high end response, which is interactive with the volume knob.

MODE
Toggle between Vibrato mode (Left/Crescent Moon) and Chorus mode (Right/Full Moon).

BYPASS ON/OFF

9V
Standard 5.5mm x 2.1mm power supply.
Polaris has internal polarity protection.



RATE
Controls the overall modulation speed.


FOCUS
Controls the overall modulation depth.

FOCUS II
Controls the overall modulation depth when the right footswitch is engaged. This feature allows access to two independent depth levels on the fly!

FOCUS II ON/OFF

(VIBRATO vs. CHORUS)

The vibrato effect is achieved when the pitch of a signal is raised and lowered. The chorusing effect is achieved by mixing this vibrato (pitch shifted) signal with the dry (non-pitch shifted) signal. The amount of vibrato signal included in this combination is known as the chorus depth. On Polaris, the two depth controls are labeled Focus and Focus II.



IN/OUT: 1/4 Jack

POWER: 9VDC ☉☉☉ | 40mA Consumption

Note: We recommend using an isolated power supply. Daisy chained power supplies are not recommended.